


THIS DRAWING AND THE INFORMATION CONTAINED THEREON ARE THE EXCLUSIVE PROPERTIES OF PTL ENGINEERING INC. IT SHALL NOT BE COPIED OR DUPLICATED WITHOUT OUR WRITTEN CONSENT

		REVISION



DOOR SIDE

REMOVE THE POS-A-LOC FORM THE TOP OF THE DOOR
OPTIONAL: REMOVE THE CABLE FROM THE INSIDE OF THE DOOR.


MOUNT THE PLATE ON THE TOP OF THE DOOR TRIM. IT IS MOUNTED FLUSH WITH THE RIB LOCATED ON THE TRIM (A) AND 9" FROM THE HINGE SIDE OF THE DOOR (B). THE HOLES MUST BE PRE-DRILLED IN THE ALUMINUM TRIM WITH A 1/8" BIT. DO NOT PRE-DRILL THE STEEL TUBE.

MOUNT THE SCREWS IN THE MIDDLE OF THE 2 SLOTS FIRST (C). THIS IS SO THAT YOU CAN ADJUST THE PLATES IF NECESSARY. AFTER THE FINAL ADJUSTMENTS ARE MADE YOU CAN INSTALL THE LAST 6 SCREWS (D).

JAMB SIDE

MOUNT THE PLATE ON THE INSIDE OF THE DOOR JAMB. IT IS MOUNTED 1/2" FROM THE FLANGE OF THE JAMB (E) AND 10 5/8" FROM THE HINGE SIDE OF THE JAMB. MOUNT THE SCREWS IN THE MIDDLE OF THE 2 SLOTS FIRST (F). THIS IS SO THAT YOU CAN ADJUST THE PLATES IF NECESSARY. AFTER THE FINAL ADJUSTMENTS ARE MADE YOU CAN INSTALL THE LAST 5 SCREWS

NOTE: THE ABOVE DIMENSIONS ARE FOR A SQUARE DOOR. IF YOU HAVE AN ANGLED DOOR, HOLD A STRAIGHT EDGE UP TO THE HINGE SIDE OF THE DOOR AND USE THE SAME MEASUREMENT AS YOU WOULD ON A SQUARE DOOR.



PART NUMBER 001-444

DESIGNED BY:	DATE:	P. T. L. ENGINEERING	DESCRIPTION
DRAWN BY: C. EDWARDS	DATE: 8-25-16	3333 JOHN CONLEY DR. (810) 664-2310	DOOR CHECK
CHECKED BY:	DATE:	LAPEER, MI 48446 FAX (810) 664-2360	MOUNTING LOCATIONS
SCALE	SHEET NO. OF SHEETS	CUSTOMER INFO.: ALL	DRAWING NO.
			1000 series replacement